PARTS LIST

for

KitchenAid®

4 1/2 QT. STAND MIXER

CLASSIC - LIFT

MODELS:

KSM450BK0 (Imperial Black) KSM450ER0 (Empire Red)




FOR CUSTOMER SATISFACTION ALWAYS USE FACTORY SPECIFICATION PARTS



ST. JOSEPH MICHIGAN 49085

COLOR VARIATION PARTS

For Models: KSM450__0



COLOR VARIATION PARTS

For Models: KSM450__0

Illus	. Part	
No.	No.	DESCRIPTION
1		Motor Housing
	9704790	
	240291–21	
2		Trim Band
	W10140842	Black
3		Lower Gearcase
	9709957	Imperial Black
	9704499	
4		Planetary
	9704797	Imperial Black
_	240286–23	
5	0704005	End Cover
	9704805 240253–22	Imperial Black Empire Red
6	240233-22	Bowl Support
U		And Pins
	9704800	
	3179318	
7		Column
	9704802	Imperial Black
	9702393	Empire Red
8		Base & Foot
	0704000	Assembly
	9704803	•
	3179299	Empire Red


Colors Subject To Change. Any Color Not Listed is No Longer Available. If Additional Colors Are Added, This Page Will Be Updated.

CASE, GEARING AND PLANETARY UNIT For Models: KSM450_0

Illus. No.	. Part No.	DESCRIPTION
	xlok	
1 2	242765 2	Motor Housing
2	242765–2	Cap, Attachment Hub
3	9709194	Thumb Screw
4	**	Band, Trim
5	3180161	Washer, Fiber
6	W10112253	Gear, Worm
7	240308	Worm Gear Bracket
		and Bearing
8	9705444	Pin
9	240210-2	Shaft & Pinion
10	9705130	Gear, Attachment
		Hub Bevel
11	9709627	Bevel Pinion
4.0	0.40000	and Center Gear
12	240026	Shaft, Vertical
40	040040 4	Center
13	240018–1	Pin (Vertical Center Shaft)
14	9705443	Pin, Groove
15	4162324	Gasket, Transmssn
16	67500-55	"O" Ring
17	3180163	Washer
18	**	Lower Gearcase
19	103994	Screw
20	4176067	Shaft, Agitator
21	9703438	Ring, Retaining
22	9704677	Pin, Groove
23	4162914	Screw
24		Cover, End
25	311932	Screw
26	3400022	Screw
27	240309–2	Worm Gear Bracket
28	4160474	and Gear Center Shaft and
20	4100474	"O" Ring
29	8533910	Washer
30	3400025	Screw
31	3400026	Screw
32	9703903	Pinion, Gear
		(Agitator Shaft)
33	9706090	Washer, Shim
34	*ok	Planetary
35	240285	Ring, Planetary
		Drip
36	9703904	Gear, Internal

**Refer to Page 3 Color Variation Parts

MOTOR AND CONTROL PARTS




MOTOR AND CONTROL PARTS

For Models: KSM450_0

Illus No.	. Part No.	DESCRIPTION
1	110679	Screw, Pivot
2	116241	Washer, Spring
3	110211	Lever, Speed
J		Control Assembly
	9709276	Black
4	3183680	Spring, Control
4	3103000	Plate
5	9704324	Washer, Ball
3	3704324	Bearing (Front)
6	9708315	Armature & Bearing
O	9700313	
7	3180162	Assembly Washer
8	16998	Stud, Governor Drv
9	3180526	Bracket, Bearing
10	040775 4	Assembly
10 11	240775-1	Seal, End
	W10131078	Nut
12	3180238	Washer
13	240769	Screw, Stator
14	W10068270	Washer, Lock
15	3184176	Speed Link & Cam
16	240205	Spring, Flat
17	9702695	Field Assembly
18	4162634	Sleeve, Motor Stud
19	9706416	Brush & Spring
		Assembly
20	9707926	Screw, Set
21	4162546	Brush Holder Assy
22	3179908	Housing, Brush
		Holder
23	240680	Insert, Brush
		Holder
24	116286	Cap, Spring
		Seat
25	116287	Spring, Cap
26	3184212	Cap, Brush Holder
27	W10068260	Screw
28	W10119326	Control Plate
		Assembly
29	17830	Governor Assembly
30	9706595	Phase Control
		Board
31		Cord, Power
	W10164883	Black
32	3184609	Screw, Self Tap

BASE AND PEDESTAL UNIT

For Models: KSM450_0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BASE AND PEDESTAL UNIT

For Models: KSM450__0

Illus		DESCRIPTION
No.	No.	DESCRIPTION
1		Literature Parts
	W10171783	Use & Care Gde, Bi
	W10216827	Repair Parts List
3	W10146362	Bowl, 4 1/2 Qt.
4	240185	Pin, Bowl Locating
5	3182857	Latch, Bowl Spring
6	3400024	Screw
7	*lok	Bowl Support & Pns
8	*ok	Base & Foot Assy
9	9708649	
10	9704608	
11	9085	
12	240169	Bracket, Bowl Lift
13	WS00323	
14	9237	-1 3
15	8533907	Nut
16	3182904	
18	240235-4	
19	3183233	, 3
20	9704309	1 /
21	241764	Arm, Bowl Lift
22	240912	Screw
23	9703442	,
24	9079	Handle, Bowl Lift
25	2400040	Column Assembly
26	3400018	Screw
**Defeate Desea		

**Refer to Page 3 Color Variation Parts

ACCESSORY PARTS

For Models: KSM450 0

Illus. Part

No. No. DESCRIPTION

FOLLOWING PARTS NOT ILLUSTRATED

4164778 Mixer Attachment Pak (Includes Food Grinder (FG-A), Food Strainer (FVSP), And Vegetable Slicer. (RVS-A) (FPP-A) 4164749 Food Grinder (FGA) 8211924 Grain Mill (KGMA) 4164768 Pasta Maker And Food Grinder (Includes SNP Pasta Maker Plates) (SN/FG-A) 4164775 Fruit/Vegetable Strainer Parts (Use With FG-A Model Only) (FVSP) 4164750 Rotor Slicer/Shredder (With 4 Standard Cones) Fine Shredder, Coarse Shredder. Thick Slicer, And Thin Slicer (RVS-A) 3177975 Pouring Shield (KPS2ČL) 4164824 Pasta Maker Plates (SNP-A) 4164774 Fruit/Vegetable Strainer And Food Grinder (FVS/FG-A) 3180616 Cover, Decorative (Cotton Polyester) 4162838 Food Tray (FT) 4164748 Juicer (JÉ) 4164747 Can Opener (CO) 4164803 Sausage Stuffer Kit (SSA) 4162154 Water Jacket (K5AWJ) 3177925 Bowl Cover, Plastic Non-Sealing

4176100 5 Qt. Bowl,

Steel 4164839 Speed Disc

Polished Stainless

(Service Tool)
4160588 Grease, Planetary
8212519 Ice Cream Maker
(KICA0WH0)